PREMIER ASSET RECOVERY GROUP INSTRUCTIONS FOR MACHINERY MOVERS, RIGGERS & BUYERS

- 1. Provide Certificate of Insurance naming both Premier Asset Recovery Group and Seller as certificate holders. Certificate must show a \$1,000,000.00 of Liability Insurance.
- 2. All machines must be disconnected at the power box. No wires or air hoses are to be left hanging from the ceiling or wall. Wires must be pulled to the 1st junction box and terminated.
- 3. Where there are pipes or exhaust pipes going through the roof or wall, they must be disconnected at the first inside joint. Any holes left in roof or ceiling will be repaired by the machinery mover or buyer.
- 4. Riggers and/or owners are responsible for disposing of any oils or coolant removed from the machines.

5. All oil spills must be cleaned up.

- 6. Any torching or burning will require adequate fire suppression equipment immediately at the work point.
- 7. Any damage or accidents are to be reported immediately.
- 8. Buyers & movers must comply with all safety and OSHA laws & regulations.